

NX-148 LCD CODE PAD

TABLE OF CONTENTS

Glossary Of Terms	4
Understanding The Lights	5
Code Pad Functions	
Arming In The ON Mode	6
Making The System Ready To Arm	7
Using Quick Arm	7
Arming In The PARTIAL Mode	7
Disarming The System	8
Bypassing Zones	8
Group Bypassing	9
Un-bypassing	9
View Zone Status	9
Setting Code Pad Tones	10
View Alarm Memory	10
Test Function	11
Change User Codes	11
Assigning User Code Authority	14
Reset Function	15
Reading The Event Log	15
Setting The System Clock	16
Using The Door Chime Feature	16
Multi-Area Systems	17
Service Display	20
Emergency Activation Keys	23
Evacuation Plan	24

ZONE DESCRIPTIONS

01 _____	17 _____	33 _____
02 _____	18 _____	34 _____
03 _____	19 _____	35 _____
04 _____	20 _____	36 _____
05 _____	21 _____	37 _____
06 _____	22 _____	38 _____
07 _____	23 _____	39 _____
08 _____	24 _____	40 _____
09 _____	25 _____	41 _____
10 _____	26 _____	42 _____
11 _____	27 _____	43 _____
12 _____	28 _____	44 _____
13 _____	29 _____	45 _____
14 _____	30 _____	46 _____
15 _____	31 _____	47 _____
16 _____	32 _____	48 _____

FUNCTION CODES

Function Code	Functions Performed
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____

ENTRY / EXIT DELAY TIMES

Exit Delay Time _____	Secondary Exit Delay Time _____
Entry Delay Time _____	Secondary Entry Delay Time _____

THIS MANUAL IS PROVIDED TO HELP YOU UNDERSTAND YOUR SECURITY SYSTEM AND BECOME PROFICIENT IN ITS OPERATION. ALL USERS OF YOUR SECURITY SYSTEM SHOULD READ AND FOLLOW THE INSTRUCTIONS AND PRECAUTIONS IN THIS BOOKLET. FAILURE TO DO SO COULD RESULT IN THE SECURITY SYSTEM NOT WORKING PROPERLY. THIS BOOKLET SHOULD BE KEPT IN AN ACCESSIBLE LOCATION FOR THE LIFE OF THE SECURITY SYSTEM. IF YOU DO NOT UNDERSTAND ANY PART OF THIS MANUAL YOU SHOULD NOTIFY YOUR INSTALLING COMPANY.

The SECURITY CONTROL can be turned on (ARMED) and off (DISARMED) by entering a 4 or 6 digit code into the Code Pad Control, which is similar to a telephone Code Pad. If your Security Control has been so programmed, you may be able to turn on (ARM) your System by simply pressing the [ON] or [PARTIAL] key. The system should always be disarmed using a 4 or 6 digit code. The LED Code Pad includes up to 35 lights and a built-in electronic sounder. These provide specific information relating to the status of the security system which is described in the booklet. Understanding what the lights and sounds mean will help you to easily operate your system.

READ THE ENTIRE MANUAL AND, IF POSSIBLE, PRACTICE ON THE CODE PAD CONTROL WHILE YOUR PROFESSIONAL INSTALLER IS ON SITE. KEEP IN MIND, THE LEVEL OF SECURITY YOU WILL OBTAIN WITH THIS SYSTEM RELATES SPECIFICALLY TO THE FOLLOWING MAJOR FACTORS:

1. The quantity, quality, and placement of security devices attached to this system.
2. The knowledge you have of the security system and how that knowledge is utilized in a weekly test of the complete system.

YOU SHOULD BE AWARE OF THE FOLLOWING FACTS WHEN PREPARING A SAFETY/SECURITY PLAN FOR YOUR HOME/BUSINESS.

1. Your security system is an electronic device and is subject to failure or malfunction. Do not rely on it as your single source of security.
2. Your system should be tested weekly.
3. Your system will not work without power.
4. Warning devices will need to be loud enough, wired correctly, and properly placed to provide notification of an alarm event.
5. Smoke and heat detectors may not detect heat and smoke in all situations.
6. Use qualified security professionals to install and maintain your security system.
7. It may be possible to arm the security system without the backup battery connected. Your periodic test should be done with A.C. Power removed to verify the battery is connected and adequately charged.
8. Care should be taken to plug in and restrain the A.C. Transformer after testing.

PLEASE READ THE FOLLOWING INFORMATION AND INSTRUCTIONS CAREFULLY BEFORE OPERATING YOUR SECURITY CONTROL SYSTEM. IF YOU DO NOT UNDERSTAND ANY PORTION OF THIS MANUAL, OR IF YOU HAVE ANY QUESTIONS

**ABOUT YOUR SYSTEM, CONTACT THE INSTALLING COMPANY LISTED ON PAGE 12
OF THIS BOOKLET.**

GLOSSARY OF TERMS

Abort Delay: An option that allows a delay in reporting to the central station.

Authority Level: The level of access an individual has when using an alarm panel.

Central Station: Location where alarm data is sent during an alarm report.

Chime Feature: An option that allows the code pad to sound a ding-dong whenever an entry/exit door is opened.

Codes: Can be either User Codes (relating to a person) or Function Codes (a toggle switch to turn specific functions on/off). NOTE: A system may have either 99 four (4) digit codes or 66 six (6) digit codes, but not a mixture of the two.

Duress Code: An option that allows a special code to be sent to the central station that indicates the alarm system is being operated under duress.

Forced Arming: An option that allows the system to be turned on (ARMED) with one or more zones open. A system that is ready to be "force armed" will flash the *ready light*. (Note: Those zones that are not ready will not create an alarm.)

Function Code: A Function Code is either a four (4) or six (6) digit code that has been programmed by the installer to operate a device.

Group Bypass: An option that allows the user to bypass multiple zones with a single operation.

Master Code: A master arm/disarm code that can program other user codes.

Multi Area System: A system divided into multiple areas in which its own user or users control each area.

Partial Arm: A mode used to arm the perimeter and unused areas of an occupied premises.

Perimeter: The outer edge of the protected area.

Quick Arm: An option that allows you to turn on (ARM) the security system by pressing either the [ON] or [PARTIAL] key on the code pad control (for ARMING only) as programmed by the installing company.

Universal Arming (Uni Arm): When enabled, your alarm system can automatically determine whether to arm in the Full mode or in the preset Partial mode by looking to see if you exit your premises or stay inside after arming your system. Note: This feature can be used in conjunction with "Quick Arm".

User Code: A four (4) or six (6) digit entry used to arm or disarm the system.

UNDERSTANDING THE LIGHTS

Armed Light

The *armed light* is "on" when the system is armed. The *armed light* is "off" when it is disarmed. The *armed light* will flash when there has been an alarm during the previous arm cycle.

Bypass Light

The *bypass light* is "on" when any zone in this code pad's area is bypassed. The zone(s) that is bypassed will also be illuminated. If the *bypass light* is "off", no zones are bypassed.

Chime Light

The *chime light* is "on" when the chime feature is "on"; "off" otherwise.

Exit Light

The *exit light* is "on" during the exit delay. Please note that the light will flash during the last 10 seconds of the exit delay as a warning that the time is running out. (The user may want to restart the exit delay if the *exit light* is flashing in order to prevent an alarm. The user may then press the [Exit] key to restart the exit delay before the delay expires.)

Fire Light

A steady *fire light* means a fire zone has been faulted. A rapidly flashing *fire light* means that a fire zone is in a trouble condition.

On Light

The *on light* is "on" when the system is armed. The *on light* is "off" when it is disarmed.

Partial Light

The *partial light* is "on" when the system is armed in the Partial Mode. All non bypassed zones will be delayed and follow the Partial delay time. When armed in Partial Mode, the Arm, On, and Bypass lights will also be "on".

Power Light

The *power light* is on if the primary power is on. The *power light* will flash if the system has a low battery condition.

Ready Light

The *ready light* is "on" when the system is ready to arm and "flashes" if ready to force arm. The *ready light* is off when the system is not ready to arm because of a zone(s) being faulted.

CODE PAD FUNCTIONS

ARMING YOUR SYSTEM IN THE "ON" MODE

ON is utilized when the user is going away from the premise and wants the interior protected. Listed below are the steps to arm in the ON Mode:

Step 1 Close all protected doors and windows.

- *Ready light* will be on or flashing when all protected zones and sensors are secure. **NOTE: If any zones are bypassed, a sensor in that zone can be violated without affecting the *ready light*.**

**System Ready
Type Code to Arm**

- The security system will not arm if the *ready light* is off. Refer to "Making the System Ready to Arm" below.

**System Not Ready
For help, press •**

- If the *power light* is off, you have no AC power. Restore power if possible. If not, contact your installing company listed on page 12.




Step 2 Enter your 4 or 6 digit user code to arm the system.

- The *armed and exit lights* will illuminate.
- You may now leave the building.

**System Armed
All Zones Secure**

NOTE: The *exit light* will flash rapidly for the last 10 seconds of the exit delay as a warning to the user that the exit time is about to expire. The user may wish to disarm and rearm the system if more time is needed.

MAKING THE SYSTEM READY TO ARM

If the *ready light* is not on or if it is flashing, a zone is not secure. To identify this zone, use the scroll keys   to the right of the display to browse through the zones that are not normal. If you wish to bypass or un-bypass one of these zones, press the [BYPASS] key while that zone is being displayed. When finished viewing the zones, press the  key to return to the code entry screen.

USING THE QUICK ARM

The Quick Arm feature may be used if it is enabled. Quick Arm will allow the user to arm the security system in the ON mode by pressing the [ON] key. The system can be quick armed in the PARTIAL mode by pressing the [PARTIAL] key. This feature is used for ARMING ONLY, and will not disarm the security system. This is ideal for a maid or baby sitter code, etc.

ARMING SYSTEM IN "PARTIAL" MODE

PARTIAL is utilized when the user is inside the premise and wants protection around the perimeter. The steps to arm in the PARTIAL Mode are as follows:

Step 1 Close all protected doors and windows.

- *Ready light* must be on or flashing when all protected zones and sensors are secure. **NOTE: If any zones are bypassed, a sensor in that zone can be violated without affecting the *ready light*.**
- The security system will not arm if the *ready light* is not on or flashing.
- If the *power light* is off, you have no AC power. Restore power if possible. If not, contact your installing company listed on page 12 of this booklet for service.

**System Ready
Type code to arm**

Step 2 Press the [PARTIAL] key.

- The *bypass light* will illuminate indicating that all interior zone(s) are bypassed. (All interior devices will bypass automatically, giving the user freedom of movement within the interior area.)
- The *partial light* will not illuminate. **NOTE: All non 24 hour zone are delayed.**

DISARMING THE SYSTEM

When you enter the protected area through one of the designated Entry/Exit doors, the keypad control will sound a continuous tone for the duration of the entry delay time, or until you enter a valid code.





- Enter a valid user code.
- The red *armed light* will go off and the tone will stop. The security system is now DISARMED. If a valid code is not entered before the end of the entry delay, an alarm will occur. **NOTE: If the red *armed light* is flashing during the entry delay, the alarm system has been activated in your absence. Leave the building immediately and call your alarm company and/or the police from a safe location.**






BYPASSING ZONES






If you wish to bypass one or more zones, this must be done while the system is in the disarmed state. If the zone is not known, refer to Procedure #2.

Procedure #1: If you know the number of the zone to bypass, use the following steps:



- Step 1 Press the [BYPASS] key.
- Step 2 When the LCD prompts for a code (optional, if programmed), enter your user code.
- Step 3 The *bypass light* flashes.
- Step 4 Enter 1 or 2 digits indicating the zone you wish to bypass.
(Example: Press the   keys for zone 1, or   for zone 12.)
- Step 5 Repeat step 4 for any other zone(s) that need to be bypassed.
- Step 6 Press the [BYPASS] key again to exit the Bypass Mode. The

bypass light will stop flashing upon exiting the Bypass Mode.
Pressing the   scroll keys will display all bypassed zones.
Press the  key to exit this viewing mode.

Procedure #2: If you do not know the number of the zone you wish to bypass, use the following steps:

- Step 1 Press   The description for zone 1 will be displayed.
- Step 2 Use the   scroll keys to browse through the custom descriptions for the zones in this system.
- Step 3 To bypass or un-bypass a specific zone, press the [BYPASS] key while that zone is displayed.
- Step 4 When finished, press the  key to return to the code entry screen.



GROUP BYPASS

By pressing the [BYPASS] key, followed by the   keys, then the [BYPASS] key again, all zones that are designated as group bypass zones will be bypassed.

UN-BYPASSING

To manually un-bypass zones, perform the bypassing procedure on a zone that is already bypassed. **NOTE:** All zones will automatically be un-bypassed each time the system is disarmed.

VIEW ZONE STATUS

- Step 1 Enter  . The LCD Screen will display the zone status.
- Step 2 Use the up and down scroll keys to browse through the descriptions.
The LCD Screen will display the list of all zones in sequential order by zone number.
- Step 3 Press [#] to exit this function.

WALK-TEST MODE


Step 1 Press [*] [Chime].

Step 2 Enter a "Master Arm/Disarm Code". Now all zones become 24 hour, silent, and local (non-reporting zones). By faulting any zone, that zone will latch its zone light on the LED code pad, and sound the Chime. The Chime will continue to sound each time a zone is faulted.


Step 3 Once all zones are tested (zone lights lit on the LED code pad), press a "Master Arm/Disarm Code".


SETTING THE CODE PAD TONE

Step 1 Press  . Code Pad is now in the "Adjust Tone" mode.



Step 2 Press the  up scroll key located on the right side of the display to make the code pad sounder go to higher tones.

Raise tone	•
Lower tone	•

Step 3 Press the  down scroll key to make the code pad sounder adjust to lower tones.

Step 4 When the desired tone is reached, press the  key to set this tone and exit from the "Adjust Tone" mode.

VIEW ALARM MEMORY

Step 1 Press   to display the zone(s) on the code pad that created the last alarm.


Step 2 The LCD Screen will display the zone description for those zones.

Step 3 Press [#] to exit the alarm memory.

Alarm Memory 1
ZONE 1

TEST FUNCTION (Optional, if programmed)

If programmed, this function will perform a battery test, communicator test, and/or a siren test. No alarms will be sent, and no reports will be sent unless a communicator test is performed, in which case a test signal will be sent.

Step 1 Press   4 . The test will be performed as programmed.

Step 2 If the siren test is performed, enter a user code to silence the siren.

CHANGING USER CODES

Step 1 Press   5 . The LCD Screen will prompt for a code.

Step 2 Enter [master code]. The LCD Screen will prompt for a user number. **NOTE: For partitioned systems, if you are changing the code of another person, you must have access to all partitions, or at least all of the partitions to which the other person has access.**

Step 3 Enter the 2 digit user number (always 2 digits, i.e. "03" for user 3). The LCD screen will prompt for a new code. **NOTE: To delete a user code, press [Chime]-[Chime]-[Chime]-[Chime] for a 4-digit code or [Chime]-[Chime]-[Chime]-[Chime]-[Chime]-[Chime] for a 6-digit code.**

Step 4 Enter the new user code designated for that individual. If it rejects the code because of a duplication or such, the sounder will beep 3 times.

Step 5 If another user code needs to be programmed, return to step 3 and enter the user code.




Step 6 To exit Code Programming, press  while the LCD screen is prompting for a new user.

Photo layout (Page 12 & 13)

ASSIGNING USER CODE AUTHORITY LEVELS

Assign authority levels to users by following the steps below. Assign user codes before assigning authority levels. **NOTE: You must have authority to the partition you wish to add or remove from another person's authority.**

Step 1 Press  . The LCD Screen will now prompt for a code.

Step 2 Enter [master code]. The LCD Screen will prompt for a user number.

Step 3 Enter the 2 digit user number (always 2 digits, i.e. "03" for user 3). The LCD will now prompt you for the attributes in the following chart.

PROMPT	
Outputs used?	• DO NOT CHANGE THIS SEGMENT! (It is for use by a professional installer only.)
Open / Close Rprt?	
Bypass enable?	
Arm / Disarm?	
Master code?	0=No 1=Yes Your key-press will apply to the user code you entered in Step 3.
Sched arm only?	
Arm only?	
Reserved	
Output 4 ?	If these messages appear on the LCD screen, press the [*] key until you return to the prompt for the user code or until you exit this adjust mode.
Output 3 ?	
Output 2 ?	
Output 1 ?	

Step 4 **NOTE:** The LCD will now display all of the partitions to which this user has access. If you wish to remove a partition, press the partition number on the code pad, and the display will mark that partition with a (-) hyphen indicating access has been removed. If you wish to re-establish user access to the partition, press the partition number again.

Step 5 Press [*] to save the data. The LCD will then prompt you for the next user code.

Step 6 If another user code needs to be programmed, return to Step 3. If not, press [#] to exit this feature without saving the data.

RESET FUNCTION

This function is used to reset Smoke Detectors, Zone Troubles, and Zone Tamperers.

Step 1 Disarm the system if it is not already disarmed.

Step 2 Press  . Resets have now been performed.


Step 3 If the code pad begins beeping, the reset did not execute properly. Enter your code to silence the code pad. Wait a few minutes and repeat step 2 to attempt another reset. If the code pad still beeps after repeated attempts, please contact your installer.


READING THE EVENT LOG

The NX-16 has a 185 event log that can be retrieved using a master code. This log contains a listing of the last 185 events along with date, time, and partition where the event occurred.

Step 1 To view the log, press   . The LCD screen will prompt you for a code.

Step 2 Enter your master code. The LCD screen will now show the most recent event.






Step 3 To view the events from most recent to the oldest, press the  down scroll key.

Step 4 To view the events from the oldest to the newest, press the  up scroll key. The display contains the following information.







Event	•	Open	75	•	User or Zone ID
Date	•	9/25	17:57	•	Indicates partition
(Month/Day)			P3	•	and • indicates an event not reported

This screen shows an opening of Area 3 on September 25th at 5:27 p.m. by user 75. The [•] shows that this event is not programmed to be reported to the central monitoring station.

ADJUSTING THE VIEW / BRIGHTNESS OF THE LCD

- Step 1 Enter    The LCD Screen will prompt for a code.
- Step 2 Enter [master code]. The LCD will now prompt you to raise or lower the view.
- Step 3 Using the scroll keys to the right of the LCD, you can raise the text or lower the text.
- Step 4 To advance to the Brightness option, press []. The LCD will prompt you to brighten or dim the LCD lighting. Use the scroll keys again to adjust to desired brightness.
- Step 5 When completed, exit by pressing [].

SETTING THE SYSTEM CLOCK



- Step 1 Enter    The LCD Screen will prompt for a code.
- Step 2 Enter [master code]. The time and date will be displayed with the current hour flashing.
- Step 3 Use the   scroll keys to select the proper hour.
- Step 4 Enter the  key to move to the minutes, day of week, date, month, and year.
- Step 5 Repeat Steps 3 and 4 until the entire time and date are set.

USING THE DOOR CHIME FEATURE

The door chime is turned on or off by pressing the [CHIME] key. If the chime is on, the *chime light* will be illuminated. If the chime is off, the *chime light* will be off. Each press of the [CHIME] key will toggle the chime feature on/off and produce a momentary ding-dong sound.

MULTI-AREA SYSTEMS OPERATION

If your system is multi-area and the code pad resides in one area, your code pad will provide the status of the zones in your area by using the screen messages described earlier in this manual. The Master Mode of operation allows you to temporarily access any area (providing your code is authorized) within the system and to perform functions in other areas. Read this entire manual to help you understand the different screen messages that will be displayed from your code pad.

NOTE:   will **temporarily** access the Master Mode. The code pad will revert back to its assigned area 60 seconds after a keypress, or 10 seconds without a keypress.

LIGHTS IN MULTI-AREA MASTER MODE

- **ARMED** will illuminate if ALL areas are armed.
- **READY** will illuminate if ALL areas are "Ready". The *ready light* will flash if all areas are Ready or Force armable.
- **FIRE** will illuminate if ANY one area has a Fire condition. The *fire light* will flash if ANY area has a Fire Trouble condition.
- **POWER** will illuminate if the primary power is connected to the NX-16 control panel. It will flash if the system has a low standby battery condition.
- **PARTIAL** will illuminate if ANY area has the *partial light* on.
- **CHIME** will illuminate if ANY area is in the "Chime" mode.
- **EXIT** will illuminate if ANY area is timing an exit delay. It will flash if ANY area is in the last 10 seconds of an exit delay.
- **BYPASS** will illuminate if ANY area has a zone bypassed.
- **SOUNDER** will sound if ANY area has the sounder on. This includes Entry delay, Exit delay, Chime, and Alarm.

DISPLAYS IN THE MULTI-AREA MASTER MODE

• ARMED and READY STATUS

The LCD screen will display the Armed and Ready status of ALL eight (8) areas if any or all of the areas is armed or not ready.

Ready	12345678
Armed	1234-678

This display is reflecting all 8 areas are Ready, and Area 5 is disarmed. **NOTE:** If a number is flashing on the armed line, that area is armed *Instant*. If a number is flashing on the ready line, that area is ready to be *Force Armed*.

System Ready
Type code to arm

If ALL areas are disarmed and ready to arm, this display will appear on the LCD screen.

• ARMING AND DISARMING MULTIPLE AREAS

To arm/disarm multiple areas, enter a code that has arm/disarm authority for ALL of the areas to be armed/disarmed. The following display will appear on the LCD screen.



1-4 -8	Disarm •
-3- 67-	Arm •

The numbers on the **top line** represent the disarmed areas to which this code has access. The numbers on the **bottom line** represent the areas that are armed. The following table describes the possible

conditions of an area.

LCD DISPLAY FOR AREA TOP LINE OVER BOTTOM LINE	CONDITION
Blank Blank	Area Not Used or Authorized
Dash (-) Dash (-)	Area Not Ready
Flashing Area # Dash (-)	Area Ready to Force Arm
Dash (-) Flashing Area #	Area Armed Instant
Area # Dash (-)	Area Disarmed & Ready to Arm

Dash (-) Area #	Area is Armed
--------------------	---------------

- To arm **all** of the areas, press the  down scroll key.
- To disarm **all** of the areas, press the up scroll  key.
- To toggle the condition of a single area between armed and disarmed conditions, press [*]-[Number of Area]. For example, If Area 4 is armed, [*]-[4] will disarm Area 4. If Area 4 is disarmed, [*]-[4] will arm it.
- To control the individual areas, refer to the following section "Operating Individual Areas in the Multi-Area Mode".

• OPERATING INDIVIDUAL AREAS IN THE MULTI-AREA MODE

Enter a code that is a valid arm/disarm code for the area you wish to operate. The following display will appear on the LCD screen.

12-4--78	Disarm •
--3-56--	Arm •

Only the areas authorized by this code will appear.

To toggle between the armed and disarmed states of an individual area, press [*] [Area number].

To operate an individual area, enter the number of the area desired. The LCD code pad will now operate as a single area code pad. All keys and functions entered will affect this individual area only. The lights and display represent the status of that area only. The word "System" will be replaced with the word "Area #". The following is an example of this feature. To exit this screen, press [#].

Area 5 Ready Type code to arm

Area 5 is selected and Area 5 is ready to arm. To exit the individual area mode, enter [#]-[#].







• SILENCING ALARMS IN THE MULTI-AREA MODE

If the code pad is sounding an alarm or the siren is running, it can be silenced by entering a code with the authority for the area(s) that are in alarm. **NOTE:** The [EXIT], [BYPASS], and Alarm Memory [*]-[3] function keys will only work if an individual area is selected.

SERVICE DISPLAY

The following message will be displayed periodically if the security system requires service. Call your service provider promptly if this message is observed.

**Service Required
Type - 2 for help**

If you see this display, press  . One or more of the following fault messages will be displayed. Use the scroll keys   to browse through them. To exit the service messages, press -.

**Control
Over-current**

A short circuit of a control's power supply has occurred.

**Control
Siren trouble**

Open circuit has occurred on the bell or siren circuit.

**Control
Box tamper**

(Optional) The Box Tamper circuit has activated.

**Control
Phone trouble**

The phone line connected to the control is not operating properly.

**Control
Fail to Comm.**

The control attempted to communicate a message to the Central Station, but was unsuccessful.

**Control
Ground fault**

A short to ground has been detected on a control circuit.

**Control
Loss of time**

Your system has lost total power and needs the clock reset.

**Control
Power trouble**

The main power to your system is not on.

**Control
Low Battery**

The standby battery is low.

Expansion Over-current	A short circuit of an expansion devices' power supply has occurred.
Expansion Aux. comm. fail	An auxiliary reporting device has failed to communicate.
Expansion Power trouble	The main power to an expansion power supply is not on.
Expansion Low Battery	An expansion power supply has a low battery.
Expander Box tamper	A box containing an expansion device has been opened.
Expansion Trouble	An expansion device or code pad is not reporting to the control panel.
Expansion Siren trouble	Open circuit has occurred on the bell or siren circuit of the expander.
Zone Tamper, Press •	A zone is tampered. Press [•] to identify the tampered zone.
Zone Low Batt, Press •	A wireless device has a low battery. Press [•] to identify the zone.
Zone Lost, Press •	A wireless or multiplexed zone device is not reporting to the control. Press [•] to identify the zone.
Zone Trouble, Press •	A zone is experiencing some form of trouble (probably wiring). Press [•] to

Identify the zone.

KEYPAD CONTROL TONES (BEEPS)

A sounder is built into the keypad and may sound for any of the following reasons:

- Beeps for all keypresses.
- Sounds a continuous tone during the Entry delay time.
- Pulses when a day zone is violated while the system is disarmed.
- Pulses when a FIRE zone has a trouble condition.
- Pulses when the armed status changes and the AC power is off.
- Beeps 3 times for trying to arm with the "READY" light off, if "FORCE ARMING" has not been selected.
- Beeps 1 second for the "CHIME" feature.
- Beeps 1 second at the end of the exit delay.
- Beeps to indicate telephone line fault if selected.
- Beeps 1 long beep followed by 3 short beeps to alert you that there are only ten seconds remaining in the exit delay.

When pulsing, the keypad sounder may be silenced by entering a valid code. The arm/disarm state of your system will not change when entering a code to silence a pulsing keypad sounder.

EMERGENCY ACTIVATION KEYS

NOTE: You must hold these keys for 2 seconds to activate these functions. Your system may not be programmed for these activations.



Fire



Auxiliary Emergency



Police

Fire Key - If programmed, you can activate the Fire alarm by pressing the Emergency Activation [Fire] key for two seconds. If your system is connected to a monitoring center, an emergency report could be sent to that center. This key should only be pressed in an emergency situation requiring response by fire department personnel.

Auxiliary Key - If programmed, you can activate the auxiliary alarm by pressing the Emergency Activation [Auxiliary] key for two seconds. If your system is connected to a monitoring center, an emergency report could be sent to that center. This key should only be pressed in an emergency situation requiring response by emergency personnel.

Police (Panic/Hold-Up) Key - If programmed, when the Emergency Activation [Police] key is pressed for two seconds, a local audible alarm will sound. If your system is connected to a monitoring center, an emergency report could be transmitted to that center. These keys should only be pressed in an emergency situation requiring immediate response by law enforcement personnel.

EMERGENCY EVACUATION PLAN

An emergency evacuation plan should be established for an actual fire alarm condition. For example, the following steps are recommended by the National Fire Protection Association and can be used as a guide in establishing an evacuation plan for your building.

Draw up a floor plan of your home. Show windows, doors, stairs, and rooftops that can be used for escape. Indicate each occupant's escape routes. Always keep these routes free from obstruction. Determine two means of escape from each room. One will be the normal exit from the building. The other may be a window that opens easily.

An escape ladder may have to be located near the window if there is a long drop to the ground below. Set a meeting place outdoors for a headcount of the building occupants. Practice escape procedures. In a home, sleep with bedroom door closed; this will increase your escape time. If you suspect fire, test the door for heat.

If you think it is safe, brace your shoulder against the door and open it cautiously. Be ready to slam the door if smoke or heat rush in. Practice escaping to the outdoors and meeting in an assigned spot. Call the Fire Department from a neighbour's phone. Early warning fire detection is best achieved by the installation of fire detection equipment in all rooms.